

```
"""pf_controller controller."""
```

```
import matplotlib.pyplot as plt
import numpy as np
from scipy.stats import norm
import math
import sys
import copy
```

```
from controller import Robot
from controller import Supervisor
from controller import Keyboard
```

```
from misc_tools import *
```

```
MAX_SPEED = 12.3
```

```
##### SIMULATOR HELPERS #####
```

```
# Normalizes the angle theta in range (-pi, pi)
```

```
def normalize_angle(theta):
    if (theta > np.pi):
        return theta - 2*np.pi
    if (theta < -np.pi):
        return theta + 2*np.pi
    return theta
```

```
def velFromKeyboard(keyboard):
    turn_base = 3.0
    linear_base = 6.0
    vel_left = 0.0
    vel_right = 0.0
    key = keyboard.getKey()
    while (key != -1):
        if (key==Keyboard.UP):
            vel_left += linear_base
            vel_right += linear_base
        if (key==Keyboard.DOWN):
            vel_left += -linear_base
            vel_right += -linear_base
        if (key==Keyboard.LEFT):
            vel_left += -turn_base
            vel_right += turn_base
        if (key==Keyboard.RIGHT):
            vel_left += turn_base
            vel_right += -turn_base
        key = keyboard.getKey()
    return vel_left, vel_right
```

```
def get_curr_pose(trans_field, rot_field):
    values = trans_field.getSFVec3f()
    rob_theta = np.sign(rot_field.getSFRotation()[2])*rot_field.getSFRotation()[3]
    rob_x = values[0]
    rob_y = values[1]
    return [rob_x, rob_y, rob_theta]
```

```

def get_pose_delta(last_pose, curr_pose):
    trans_delta = np.sqrt((last_pose[0]-curr_pose[0])**2 + (last_pose[1]-
curr_pose[1])**2)
    theta_delta = abs(normalize_angle(last_pose[2]-curr_pose[2]))
    return trans_delta, theta_delta

# Returns the odometry measurement between two poses
# according to the odometry-based motion model.
def get_odometry(last_pose, curr_pose):
    x = last_pose[0]
    y = last_pose[1]
    x_bar = curr_pose[0]
    y_bar = curr_pose[1]
    delta_trans = np.sqrt((x_bar - x) ** 2 + (y_bar - y) ** 2)
    delta_rot = normalize_angle(last_pose[2] - curr_pose[2])
    delta_rot1 = delta_rot / 2.0
    delta_rot2 = delta_rot / 2.0

    if (delta_trans > 0.01):
        delta_rot1 = normalize_angle(math.atan2(y_bar - y, x_bar - x) -
last_pose[2])
        delta_rot2 = normalize_angle(curr_pose[2] - last_pose[2] - delta_rot1)

    return [delta_rot1, delta_rot2, delta_trans]

def get_sensor_reading(landmarks, pose):
    px = pose[0]
    py = pose[1]

    lm_ids = []
    x = []
    y = []

    for i in range(len(landmarks)):
        lx_clean = landmarks[i+1][0]
        ly_clean = landmarks[i+1][1]
        noise = np.random.normal(loc=0.0, scale=0.5, size=2)
        lx = lx_clean + noise[0]
        ly = ly_clean + noise[1]
        id = i+1

        # calculate expected range measurement
        meas_range = np.sqrt( (lx - px )**2 + (ly - py )**2 )

        if meas_range > 5.0:
            continue

        lm_ids.append(id)
        x.append(lx-px)
        y.append(ly-py)

    return {'id':lm_ids,'x':x,'y':y}

def initialize_particles(num_particles, num_landmarks, init_pose):
    #initialize particle at pose [0,0,0] with an empty map

    particles = []

```

```

for i in range(num_particles):
    particle = dict()

    #initialize pose: at the beginning, robot is certain it is at [0,0,0]
    particle['x'] = init_pose[0]
    particle['y'] = init_pose[1]
    particle['theta'] = init_pose[2]

    #initial weight
    particle['weight'] = 1.0 / num_particles

    #particle history aka all visited poses
    particle['history'] = []

    #initialize landmarks of the particle
    landmarks = dict()

    for i in range(num_landmarks):
        landmark = dict()

        #initialize the landmark mean and covariance
        landmark['mu'] = [0,0]
        landmark['sigma'] = np.zeros([2,2])
        landmark['observed'] = False

        landmarks[i+1] = landmark

    #add landmarks to particle
    particle['landmarks'] = landmarks

    #add particle to set
    particles.append(particle)

return particles

```

##### MEASUREMENT MODEL #####

```

def eval_sensor_model(measurements, particles):
    # Correct landmark poses with a measurement and
    # calculate particle weight

    # sensor noise
    R_t = np.array([[1.0, 0],
                    [0, 1.0]])

    # measured landmark ids and ranges
    ids = measurements['id']
    x_dists = measurements['x']
    y_dists = measurements['y']

    # update landmarks and calculate weight for each particle
    for particle in particles:

        landmarks = particle['landmarks']
        particle['weight'] = 1.0

```

```

px = particle['x']
py = particle['y']

# loop over observed landmarks
for i in range(len(ids)):

    # current landmark
    lm_id = ids[i]
    landmark = landmarks[lm_id]

    # measured range and bearing to current landmark
    x_dist = x_dists[i] + px
    y_dist = y_dists[i] + py

    if not landmark['observed']:
        # landmark is observed for the first time

        # initialize landmark position based on the measurement and
particle pose
        lx = x_dist
        ly = y_dist
        landmark['mu'] = [lx, ly]
        landmark['sigma'] = R_t
        landmark['observed'] = True

    else:
        # landmark was observed before

        C = np.identity(2)

        # Calculate measurement covariance and Kalman gain
        S = landmark['sigma']
        Q = C.dot(S).dot(C.T) + R_t
        K = S.dot(C.T).dot(np.linalg.inv(Q))

        # Compute the difference between the observed and the expected
measurement
        lm_arr = np.array(landmark['mu'])
        exp_meas = C.dot(lm_arr)
        delta = np.array([x_dist - exp_meas[0], y_dist - exp_meas[1]])

        # update estimated landmark position and covariance
        landmark['mu'] = landmark['mu'] + K.dot(delta)
        landmark['sigma'] = (np.identity(2) - K.dot(C)).dot(S)

        # compute the likelihood of this observation
        fact = 1 / np.sqrt(math.pow(2 * math.pi, 2) * np.linalg.det(Q))
        expo = -0.5 * np.dot(delta.T, np.linalg.inv(Q)).dot(delta)
        weight = fact * np.exp(expo)

        # calculate overall weight, account for observing
        # multiple landmarks at one time step
        particle['weight'] = particle['weight'] * weight

# normalize weights
normalizer = sum([p['weight'] for p in particles])

for particle in particles:
    particle['weight'] = particle['weight'] / normalizer

```

```

    return

##### MOTION MODEL #####
def sample_normal(mu, sigma):
    return np.random.normal(mu, sigma)

def sample_odometry_motion_model(x, u, a):
    """ Sample odometry motion model.

    Arguments:
    x -- pose of the robot before moving [x, y, theta]
    u -- odometry reading obtained from the robot [rot1, rot2, trans]
    a -- noise parameters of the motion model [a1, a2, a3, a4]

    """

    delta_hat_r1 = u[0] + sample_normal(0, a[0] * abs(u[0]) + a[1] * u[2])
    delta_hat_t = u[2] + sample_normal(0, a[2] * u[2] + a[3] * (
        abs(u[0]) + abs(u[1])))
    delta_hat_r2 = u[1] + sample_normal(0, a[0] * abs(u[1]) + a[1] * u[2])

    x_prime = x[0] + delta_hat_t * math.cos(x[2] + delta_hat_r1)
    y_prime = x[1] + delta_hat_t * math.sin(x[2] + delta_hat_r1)
    theta_prime = x[2] + delta_hat_r1 + delta_hat_r2

    return np.array([x_prime, y_prime, theta_prime])

def sample_motion_model(odometry, particles):
    # Samples new particle positions, based on old positions, the odometry
    # measurements and the motion noise
    # the motion noise parameters: [alpha1, alpha2, alpha3, alpha4]
    noise = [0.1, 0.1, 0.05, 0.05]
    for particle in particles:
        """
        signature of: sample_odometry_motion_model(x, u, a)
        x -- pose of the robot before moving [x, y, theta]
        u -- odometry reading obtained from the robot [rot1, rot2, trans]
        a -- noise parameters of the motion model [a1, a2, a3, a4]
        """
        particle['x'], particle['y'], particle['theta'] =
sample_odometry_motion_model(
            [particle['x'], particle['y'], particle['theta']],
            [odometry['r1'], odometry['r2'], odometry['t']],
            noise
        )

        # remember last position to draw path of particle
        particle['history'].append([particle['x'], particle['y']])

    return

##### RESAMPLING #####

def resample_particles(particles):
    # Returns a new set of particles obtained by performing
    # stochastic universal sampling, according to the particle

```

```

# weights.

# distance between pointers
step = 1.0 / len(particles)

# random start of first pointer
u = np.random.uniform(0, step)

# where we are along the weights
c = particles[0]['weight']

# index of weight container and corresponding particle
i = 0

new_particles = []

# loop over all particle weights
for particle in particles:

    # go through the weights until you find the particle
    # to which the pointer points
    while u > c:
        i = i + 1
        c = c + particles[i]['weight']

    # add that particle
    new_particle = copy.deepcopy(particles[i])
    new_particle['weight'] = 1.0 / len(particles)
    new_particles.append(new_particle)

    # increase the threshold
    u = u + step

return new_particles

```

```

##### MAIN #####
def main():
    # create the Robot instance.
    robot = Supervisor()
    robot_node = robot.getFromDef("Pioneer3dx")

    # robot pose translation and rotation objects
    trans_field = robot_node.getField("translation")
    rot_field = robot_node.getField("rotation")

    # get the time step of the current world.
    timestep = int(robot.getBasicTimeStep())

    # init keyboard readings
    keyboard = Keyboard()
    keyboard.enable(10)

    # get wheel motor controllers
    leftMotor = robot.getDevice('left wheel')
    rightMotor = robot.getDevice('right wheel')
    leftMotor.setPosition(float('inf'))
    rightMotor.setPosition(float('inf'))

```

```

# get wheel encoder sensors
leftSensor = robot.getDevice('left wheel sensor')
rightSensor = robot.getDevice('right wheel sensor')
leftSensor.enable(60)
rightSensor.enable(60)

# initialize wheel velocities
leftMotor.setVelocity(0.0)
rightMotor.setVelocity(0.0)

# create list of landmarks
n_obs = 9
landmarks = {}
for i in range(n_obs):
    obs_name = "Obs_"+str(i+1)
    obs_node = robot.getFromDef(obs_name)
    tr_field = obs_node.getField("translation")
    x = tr_field.getSFVec3f()[0]
    y = tr_field.getSFVec3f()[1]
    landmarks[i+1] = [x, y]

# get map limits
ground_node = robot.getFromDef("RectangleArena")
floor_size_field = ground_node.getField("floorSize")
fs_x = floor_size_field.getSFVec2f()[0]
fs_y = floor_size_field.getSFVec2f()[1]
map_limits = [-fs_x/2.0, fs_x/2.0, -fs_y/2.0, fs_y/2.0]

# init particles and weights
num_particles = 100
num_landmarks = len(landmarks)

# last pose used for odometry calculations
last_pose = get_curr_pose(trans_field, rot_field)

# particle initialization
particles = initialize_particles(num_particles, num_landmarks, last_pose)

# translation threshold for odometry calculation
trans_thr = 0.1

# initialize ground truth poses
gt_poses = [last_pose]
while robot.step(timestep) != -1:
    # key controls
    vel_left, vel_right = velFromKeyboard(keyboard)
    leftMotor.setVelocity(vel_left)
    rightMotor.setVelocity(vel_right)

    # read robot pose and compute difference to last used pose
    curr_pose = get_curr_pose(trans_field, rot_field)
    trans_delta, theta_delta = get_pose_delta(last_pose, curr_pose)

    # skip until translation change is big enough
    if (trans_delta < trans_thr):
        continue

    # compute odometry
    odom_raw = get_odometry(last_pose, curr_pose)

```

```

last_pose = curr_pose
gt_poses.append(curr_pose)
odom_dict = dict()
odom_dict['r1'] = odom_raw[0]
odom_dict['r2'] = odom_raw[1]
odom_dict['t'] = odom_raw[2]

#predict particles by sampling from motion model with odometry info
sample_motion_model(odom_dict, particles)

# generate sensor measurements
measurements = get_sensor_reading(landmarks, curr_pose)

#evaluate sensor model to update landmarks and calculate particle weights
eval_sensor_model(measurements, particles)

#plot filter state
plot_state(particles, landmarks, map_limits, gt_poses)

#calculate new set of equally weighted particles
particles = resample_particles(particles)

plt.show('hold')

if __name__ == "__main__":
    main()

```